

Includes: Poles Support Brace (3 pc w/paracord) Elbow Joints (x2) 90° Bends (x2) Feet (x2) Carry Bag & Graphic



Using the numbers on the frame, connect the exterior tubes. Set completed frame onto the posts of the two Feet.



Connect the 3 poles of the Support Brace. Lay the frame down and insert the assembled Support Brace into the center holes of the frame.



Starting from the top corner, pull the Graphic down, over the frame.



Adjust the Graphic and frame as needed to ensure the Graphic is straight and secure.









Using allen wrench, secure frame to steel base by tightening the aluminum studs.



Starting from the top corner, pull the fabric graphic over the frame.







Includes: Carrying case InstaStand Graphic



Table will arrive in closed position. To determine top and bottom, pneumatic pistons should extend upward (see step #2). Place the bottom panel on the floor. Place hands under opposites sides of the top panel and gently pull upwards.



Table will automatically rise to the fully open position.



the floor. Holding the bottom hem of the graphic, find the back seam and feel for the rigid cord inside the hem. Line up the back seam with the middle of one long side of the bottom panel and push the cord into the groove on the bottom panel.



Flip table right side up. Find the rigid cord in the top hem of the graphic and push it into the groove on the top panel. To ensure the graphic displays properly, do not twist the graphic.



For easy set-up you can leave the graphic on when you push the table to the closed position.





Includes: Graphic Mini X-Banner Frame





Using your graphic with openings, attach each of the four corners to the hooks on the X-Banner frame.



Ensure that the X-Banner frame is fully extended and taut in order to properly display your graphic.





Place the X-Banner body piece upright by extending the feet outward. Adjust the height of the telescoping pole on the X-Banner body piece by flipping the switch to the center position. Having the switch turned to the left or right position will lock the height of the telescoping pole.



Take the two arms with hooks and attach them to the center piece at the top of the telescoping pole on the X-Banner body piece.



Using your banner with grommets, attach each of the four corners to the X-Banner hooks, starting with the top first.



In order to properly display your banner on the X-Banner body piece, raise the telescoping pole until taut.

