


# INSTRUCTIONS


## Banner Display Stand




Includes:  
Base, w/Base Bolt  
Telescoping Center Post  
Cross Bars (x2)  
Spring Assembly  
Hook  
Tension Knob  
Carrying Bag & Graphic



**1**  
Slide Tension Knob onto the bottom segment of the Center Post. Line up Center Post with hole in top of base. Attach Base Bolt through the Base from the bottom and into the Center Post. Tighten Bolt.




**2**  
Twist the upper half of the post to extend it to full height. **Do Not Twist** the Plastic Mid-Collar. Tighten the post by rotating the upper half into the lower half.



**3**  
Remove one cap from one Cross Bar. Slide Bar through the pole sleeve at the top of the Graphic until it reaches the center cut-out. Slide Cross Bar through the T-joint at top of the Center Post, **be sure the back side of the graphic is on the side with the Center Post**. Continue sliding the Cross Bar through the Graphic pole sleeve. Reattach cap.



**4**  
Remove one end cap from remaining Cross Bar. Slide Bar through the pole sleeve at the bottom of the Graphic until it reaches the center cut-out. Slide the Hook into slot in Cross Bar. Continue sliding Cross Bar through the Graphic pole sleeve, **be sure the Hook stays in the cut-out**. Reattach cap.



**5**  
Attach one ring of the Spring Assembly to the Hook from step #4. Attach remaining ring over the Tension Knob. **Gently**, slide Tension Knob downwards until desired tension is achieved. Tighten Knob.

