

# INSTRUCTIONS

## Tent Sandbag Weights



Includes:  
Heavy duty nylon sandbags (4)

1



Set sandbag upright with zipper at the top. Open zipper compartment and fill bag with no more than 16 lbs. of DRY substrate. Fully close zipper.

2



Place sandbag so it sits on the foot section of a tent leg with the sewn on fastener attachments facing the tent leg.

3



Tightly secure the sandbag to the tent leg by wrapping the two sewn on fasteners around the tent leg. Repeat steps 2 and 3 with remaining sandbags.

### WARNINGS:

Do not fill the bag with any wet substrate. These may expand or overweight the bag, leading to leakage, tearing and failure of sandbag.

When transporting filled sandbag, supporting the bottom of the bag is recommended.

Do not attempt to move the tent after sandbags have been attached.



This product is for outdoor promotional use only and should not be left out in extreme weather conditions. Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.