


# INSTRUCTIONS

## Economy X-Banner



Includes:  
Hardware  
Carry Bag  
Graphic



1


Choose a clean surface that is larger than the graphic. Lay graphic face down.

Pick up hardware and unfold 4 arms until they gently snap in place. Repeat with center leg until it firmly snaps in place.



2


Place hardware above graphic, making sure the center leg is at the bottom of the graphic. Starting with two top arms, rotate hooks at end of arms to fit into the grommets on the graphic.



3

Repeat step 3 for the remaining arms at bottom of graphic.

*Note: Hooks on each arm can be moved by loosening/tightening the tensioners.*



4

To pull graphic taut, loosen the tensioners on each arm one at a time, and move them toward the ends of each arm. Tighten tensioners to hold graphic in place.

*Note: When assembled correctly, the arms will be bowed.*



5

Grasping the center assembly of the hardware, stand up assembled x-banner, ensuring the center leg is locked in place.

If needed, tensioners can be adjusted to balance the x-banner.

