



INSTRUCTIONS

Transformer Trunk




Includes:
Plastic Trunk
Table Base
Aluminum Legs
Table Top




1

Remove straps, open trunk and remove parts. Turn trunk bottom upside down. Push legs into holes located on the trunk bottom.




2

Place trunk top above legs. Align legs with holes in trunk top. Push trunk top down to firmly anchor on legs.




3

Place graphic material upside down starting at the trunk top. Slide graphic downwards.



4

Rotate entire stand 180° so that graphic is now right side up. Pull graphic up and over trunk bottom.



5

Place table top lid on top of stand and press down.




INSTRUCTIONS

Tower Stand




Includes:
Sectional Tube Frame
Base
Top Arm
Black Canvas Bag




1

Unfold and align sectional tube frame.




2

To connect the sectional pieces together, press the button and slide pieces together until buttons snap in place.




3

Attach the top arm to the sectional pieces you just assembled.



4

Align assembled parts over the base and screw clockwise.



5

Pull the fabric banner over the frame and over the lip of the base.




INSTRUCTIONS

PTH Hardware - 6'-15' Portable Half Drop and Teardrop



Includes:
Sectional Aluminum and Fiberglass Pole
Ground Spike
Carrying Case

The number, length and style of sectional pole pieces will vary based on banner size and shape.



1

Assemble sectional poles by placing end to end - largest to smallest.


Note: If any sectional poles slide down several inches, then they are upside down.



2

Slide the banner onto the pole via the pole sleeve, starting from the small end.

Note: Be sure to feed the hardware all the way through the sleeve, to the tip of the banner.



3

Loosen the screw of the attachment hook near the base of the pole and slide it towards the loop at the bottom of your banner. Then put that loop into the attachment hook and adjust the hook position to make banner flat (taut). Tighten the screw of the attachment hook to secure the banner. **For 15' hardware, there may be an attachment hook OR a tether line.**



4

Hammer taller portion of the ground spike fully into the ground. Then insert pole with banner onto peg. For best vertical presentation, check with a level front-to-back and side-to-side.




WARNING:
Do not hammer the shorter peg with the rubber O-rings.



This product is for outdoor promotional use only and should not be left out in extreme weather conditions. Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.

INSTRUCTIONS

Standard Cross Base



Includes:
20" Bar
23" Bar
Post
Nut
Spacer*

1

Place 20" bar on a surface with feet facing downwards. Place spacer on top, aligning spacer hole with center hole of the bar.

2

Place 23" bar on top, sandwiching the spacer between both bars. Align holes.

3

With the 20" bar on bottom, 23" bar on top, and spacer in between, marry the two bars together with the post.

4

Screw the nut onto the bottom of the post to hold the pieces together.

5

To use, separate both legs until perpendicular.

6

Slide assembled sectional pole with banner (see reverse side for instructions) onto the post of the cross base.

* Spacer may not be included with cross base. It is an optional piece and not required for use.


INSTRUCTIONS

Mini X-Banner




Includes:
Graphic
Mini X-Banner Frame

1




Stand the frame upright by extending the feet outward.

2



Using your graphic with openings, attach each of the four corners to the hooks on the X-Banner frame.

3



Ensure that the X-Banner frame is fully extended and taut in order to properly display your graphic.