

INSTRUCTIONS

InstaStand



Includes:
Carrying case
InstaStand
Graphic



1

Table will arrive in closed position. To determine top and bottom, pneumatic pistons should extend upward (see step #2). Place the bottom panel on the floor. Place hands under opposite sides of the top panel and gently pull upwards.



2

Table will automatically rise to the fully open position.



3

Flip table upside down so top panel is on the floor. Holding the bottom hem of the graphic, find the back seam and feel for the rigid cord inside the hem. Line up the back seam with the middle of one long side of the bottom panel and push the cord into the groove on the bottom panel.*




4

Flip table right side up. Find the rigid cord in the top hem of the graphic and push it into the groove on the top panel.* To ensure the graphic displays properly, do not twist the graphic.



5

For easy set-up you can leave the graphic on when you push the table to the closed position.



*Note: A spline tool (not included) may assist in pushing cord into the groove.